

MASAŽNI PIŠTOLJ MT6521

Upute za uporabu



⏻ Napajanje/Brzina



⚡ USB-C



UREĐAJ UKLJUČEN

-  1s - STATUS BATERIJE
-  2s - UKLJUČI/ISKLJUČI
-  1s - ODABIR BRZINE

Punite na 5V priloženim kablom dok svi LED indikatori ne svijetle stabilno




3x10min

CIKLUS



5min

PRESTANAK



DIJAGRAM ZA UPOTREBU NASTAVKA